



# CRAWFORD BOOTS

Waterproof Industrial  
Safety Boots



THE WEDGETECH™  
PERSONALISED  
LOCK-FIT SYSTEM



BECAUSE  
NO TWO FEET  
ARE THE  
SAME!



# SAFETY BOOTS FOR MINERS

Built on 25 YEARS of experience working with Australia's underground miners feet.

Designed to survive the tough environment of Australian underground mines and ready to take on any wet area work site in the world.



## IF THE BOOT FITS WEAR IT

Our boots are fit for purpose - underground or any wet area work sites.

Our superior waterproof safety boots are available in Electrical Shock Resistant (ESR) or Antistatic (AS) specification.

Both models are compliant with Australian and International safety standards, carry similar built-in features and incorporate our Wedgetech Personalised Lock-fit System to give you a custom fit.

## ANTI-STATIC BOOTS

Less build-up, More Protection



ANTI-STATIC OPTION

CE EN ISO 20345:2011  
S5 HRO SRA



ASTM F2413-11  
M I/75 C/75  
PR



AS/NZS 2210.3:2009  
S5 HRO SRA

SP / ASTM  
C US



ELECTRIC SHOCK  
RESISTANT

CE EN ISO 20345:2011  
SB P E FO HRO SRA



ASTM F2413-11  
M I/75 C/75  
EH  
PR



AS/NZS 2210.3:2009  
SB P E FO HRO SRA

SP / ASTM  
C US

FOR MORE INFORMATION VISIT

[www.crawfordboots.com.au](http://www.crawfordboots.com.au)

**CRAWFORD  
BOOTS**

**BECAUSE  
NO TWO FEET  
ARE THE SAME!**

**UNIQUE FEATURES**



WATERPROOF



MICROBAN  
ZPTECH™  
NEOPRENE LINER



HEEL  
COUNTER



DURABLE  
VULCANISED  
BONDED BOOT &  
SOLE



ZIPPER GUSSET



SPECIALISED  
RUBBER BOOT



NON METALLIC  
YKK ZIP



ANGLED  
BOOT TOP



6 PRECISION CUT AND  
MOLDED WEDGETECH™  
INSERTS



**BOOT FEATURES**



METATARSAL  
REINFORCEMENT



HEEL SPUR



INNERSOLE

**SAFETY FEATURES**



STEEL TOE  
CAP



SLIP & HEAT  
RESISTANT  
SOLE



PENETRATION  
RESISTANT  
MIDSOLE



ENERGY  
ABSORPTION  
HEEL



FUEL OIL  
RESISTANT  
SOLE

All Crawford Boots are certified to the following standards.



ANTI-STATIC OPTION

CE EN ISO 20345:2011  
S5 HRO SRA



ASTM F2413-11  
M 1/75 C/75  
PR



AS/NZS 2210.3:2009  
S5 HRO SRA



ELECTRIC SHOCK  
RESISTANT

CE EN ISO 20345:2011  
SB P E FO HRO SRA



ASTM F2413-11  
M 1/75 C/75  
EH  
PR



AS/NZS 2210.3:2009  
SB P E FO HRO SRA







**BECAUSE  
NO TWO FEET  
ARE THE SAME!**

## PERSONALISED WEDGETECH™ LOCK-FIT SYSTEM

### How does it work

These boots are purpose built for tough Australian underground mining conditions and ready for any wet work area. Each pair of Crawford Boots comes with six WedgeTech™ inserts. That's three sizes (S,M,L) for your left and right feet. You choose the best fit for each boot, so you get a personalised fit. You'll know when you have the correct inserts, your Crawford Boots should feel like properly laced-up joggers. Basically they fit.

The WedgeTech inserts are placed in the integrated boot pocket at the front of the ankle. The WedgeTech inserts push your foot back and down into the boot - securing your foot firmly into the boot.

### Stability for your feet.

By locking the foot into a stable position, the WedgeTech inserts make your foot more secure and fitted within the boot. When your boots fit better they don't feel heavy, there's no foot slip and no risk of your foot pulling out even in the wettest conditions.

### Happy feet, happy worker



1. Start by choosing the two **Green Inserts**, that's the **Medium thickness** for your Left and Right boots
2. Remove the Tell Tail from the pocket inside the boot and pull the pocket open.
3. Slide the inserts all the way into the open pocket and down to the bottom.
4. Take a walk in the boots and feel how firm and stable they are. If there is some movement try the **thicker inserts** – or if a bit too firm try the **thinner inserts**.
5. Some clients have the **Large** in one boot and the **Small** in another  
– **Because No Two Feet Are The Same!**
6. Once you have the inserts to suit you, simply leave the inserts in place and use the Zip to take your boots on and off.

FOR MORE INFORMATION VISIT

[www.crawfordboots.com.au](http://www.crawfordboots.com.au)



**THE WEDGETECH™  
PERSONALISED  
LOCK-FIT SYSTEM**

**BECAUSE  
NO TWO FEET  
ARE THE  
SAME!**

**FOR MORE INFORMATION VISIT  
[www.crawfordboots.com.au](http://www.crawfordboots.com.au)**

**DESIGNED IN  
AUSTRALIA**

**Made in Malaysia.**

Waterproof Industrial Safety Boots with rubber upper,  
rubber sole and neoprene sock lining.  
These boots are the subject of granted and pending patents.  
All enquiries [www.crawfordboots.com.au](http://www.crawfordboots.com.au).

© 2017 Crawford Boots

